

Using TracBack on Outdoor Touchscreen Handhelds

The TracBack feature allows you to navigate back along your previously recorded activity or track.

Most Garmin outdoor handhelds are designed to record an activity or track when powered on and connected to satellites. This is to allow you to power the device on and begin your activity.

The information and steps outlined in this article apply to the following devices¹:

- eTrex Touch Series
- Oregon 600/700 Series
- Montana 610/680 Series
- Rino 750/755t

All devices above (except the Oregon 600 series) default to recording Activity FIT files. These files are smaller, which allows for recording and storing significantly more files.

As these devices have the ability to record an activity, it is better to use the Current Activity Controls to manage the recording so a TracBack is most useful. For steps, see Related.

Performing a TracBack

1. Select **Track Manager** or **Activity History** from the main menu
2. Select **Current Track** or **Activity**
3. Select **View Map**
4. Select **TracBack**

The handheld will then begin to navigate you back to the start of your trip along the same path you took. You can also use the Map or Compass page to help navigate.

Note: A TracBack can only be performed using the current track or activity. If a saved or archived track or activity is chosen, the TracBack option will not appear.