

[< Garmin Support Center](#)

# Using TracBack on the eTrex 10/20/20x/22x/30/30x/32x

The TracBack feature allows you to navigate back along your previously recorded track.

Most newer Garmin outdoor handhelds are designed to start tracking once satellite connection is acquired. Due to this, it is best to reset the track and trip data at your starting point so your device knows the path you should follow back with TracBack. This also helps eliminate straight lines from your last known location to your current location (*ie. from your home to the current trailhead*).

**Note:** A **TracBack** can only be performed using the current track log. If a saved or archived track is chosen, the TracBack option will not appear.

## Resetting Track and Trip Data

1. Select **Setup** from the main menu
2. Select **Reset**
3. Select **Clear Track and Trip Data**
4. Select **Yes**

Both the trip data and current track should now be reset. When ready to head back to your starting point, use the steps below for TracBack.

## Performing a TracBack

1. Select **Track Manager** from the main menu
2. Select **Current Track**
3. Select **View Map**
4. Press **Enter**<sup>1</sup> to start the TracBack

The handheld will then begin to navigate you back to the start of your trip along the same track you took. You can also use the Map or Compass page to help navigate along the track.

<sup>1</sup> Press the center of the Thumb Stick down