

Using TracBack on the inReach Mini 2

The inReach Mini 2 includes a TracBack feature which can be accessed from the Navigation widget. TracBack on the inReach Mini 2 is unique in that it will be available even if tracking was not started at the beginning of an activity. This makes it a useful backup option for navigation if you forget to start tracking.

This is different from the Back to Start feature which is used to navigate back to the start of a recorded activity. For more information about the Back to Start feature, see [Related](#).

How TracBack Works on the inReach Mini 2

While the inReach Mini 2 is powered on and connected to satellites, it automatically records its location every 10 minutes to create a hidden trip log in the background that contains tracking data. This hidden trip log is what will be used when starting a TracBack from the Navigation widget.

IMPORTANT: Only the most recent 24 hours of tracking data is saved. The device will automatically discard any tracking data earlier than the last 24 hours.

Starting a TracBack From the Navigation Widget

1. From the home page, press ▲ or ▼ to scroll through the widget glances.
2. Select **Navigation**.
3. Press **OK** to open the options menu.
4. Select **Navigate**.
5. Select **TracBack**.
6. Press **OK** to open the options menu.
7. Select **Go**.

The inReach Mini 2 will now navigate back along the path that was previously traveled.