Track Information Page

To access information on a Saved Track, highlight the desired track. Press **ENTER** to display the Track Information page.

Name—allows you to change the Saved Track Name. When tracks are saved, the GPSMAP 76 uses the a date as the default track name.

Distance—shows the total distance of the Saved Track.

Points—shows the number of track log points in a Saved Track.

Area—shows the calculated acreage within the track. The end points of the track are connected with a straight line when calculating the area. If the track crosses itself, it is not accurate.

Show on Map and Highway—when checked, the Saved Track is displayed on the Map and Highway pages.

Delete Button—shows a pop-up window verifying you want to delete the Saved Track.

TracBack Button—initiates TracBack Navigation. TracBack Navigation uses Track Points in a saved track to automatically create a route. You have the option of navigating the route in the **Original** or **Reverse** direction.

Map Button—displays the Saved Track on the Map page.

OK Button—saves any changes and returns the display to the Tracks page.