

[← Garmin Support Center](#)

Using TracBack or Back to Start With a Garmin Outdoor Watch

The TracBack and Back to Start features allow you to navigate back along your current activity's recorded track. This can only be performed using the current activity log. If a saved or archived track is chosen, the option will not appear.

Performing TracBack or Back to Start

1. Start an activity that uses GPS
2. During the activity, press **Start/Stop**
3. Select **TracBack** or **Back to Start**

Your watch will now navigate back along the activity's path. Both the Compass and Map page can be utilized when following the path.

Was this page helpful?

Yes Somewhat No

SUBMIT