

## Navigating to a Saved Trip

- 1 Select **Apps** > **Trip Planner** > **Saved Trips**.
- 2 Select a saved trip.
- 3 Select **Go!**.
- 4 Select the first location to navigate to, and select **Start**.  
The device calculates a route from your current location to the selected location, and then it guides you to the remaining trip destinations in order.

## Sharing a Route

You can share routes with other zūmo devices.

- 1 Select **Apps** > **Share Route**.
- 2 Select an option:
  - To share a route using Garmin Drive, select **Garmin Drive™**.
  - To share a route using a Bluetooth connection, select **Bluetooth**.
  - To copy the route to a microSD card, select **Memory Card**.
- 3 Select a route.
- 4 Select **Done**.
- 5 Follow the on-screen instructions on your zūmo device to complete the sharing process.

## Tracks

A track is a recording of your path. The track log contains information about the recorded path, including time, location, and elevation information.

### Recording Tracks

Tracking records your path. When you start tracking, your device logs your location and updates the track line. If your device is paired with a Garmin Explore account, your device periodically synchronizes recorded tracks with the app.

- 1 From the main screen, select **Track**.
- 2 Select **Start**.

## TracBack™

### Following Your Recent Track

The TracBack feature records the most recent segment of your movement. You can retrace your recent track back to a previous location.

- 1 Select **Apps** > **TracBack**.  
Your recent track appears on the map.
- 2 Select **Go!**.

### Saving Your Recent Track as a Trip

You can save your recent track as a trip, which you can navigate later using the trip planner (*Navigating to a Saved Trip*, page 49).

- 1 Select **TracBack**.  
Your recent track appears on the map.
- 2 Select  > **Save as Trip**.
- 3 Enter a name, and select **Done**.